

Controlled Independent Ball Valve

Scope of Use / Specification Sheet

Breechings are available in controlled or uncontrolled and dividing and collecting types. Dividing Breechings are usually used at the outlet of a standpipe to divide from one water source to two. Collecting Breechings are predominately used at the back of the truck so they can have 2 water sources to help feed extra water into the pumping appliance.



FS6037

Parts List

Order Code	Description
FS6037	Breeching Storz 65x2x65 BV LA
FS6038	Breeching Storz 65x2x40 BV LA
FS6053	Breeching QRT 65mm Female x2x65mm BV LA
FS6070	Breeching BIC 65x2x BV
FS6034	Breeching Storz 40x2x40 BV
FS6035	Breeching Storz 40x2x25 BV

Installation

Installation is subject to the requirements of the applicable regulatory authority, the National Construction Code Volume Three – Plumbing Code of Australia, associated reference standards as applicable at the time and AS/NZS 3500. For further Scope of Use, please visit matthewsfirealarm.com.au/brochures